

SELECT BASIC

Assembly instruction

Mounted on cabinet bottom.



1.



2. Place the frame on the cabinet bottom.



3. Measure a minimum distance of 30mm from the edge of the cabinet to the frame.



4. Attach the frame on the cabinet bottom using 4 screws.



5.



6. Insert bins, lid and divider.