

# CUBE

## Assembly instruction

Mounted on drawer bottom.



- 1.** Unfold the sides of the frame. Angle in the lower part of the sides of the frame.



- 2.** Place the frame in the drawer.



- 3.** Attach the frame on the drawer front using 2x2 screws. Use the outer holes.



- 4.** Attach the frame on the bottom of the drawer using 2x2 screws.



- 5.** Insert bins, lid and dividers.