SELECT SIDE

Assembly instruction

Mounted on cabinet side.



 Place the side bracket depending on which side of the cabinet you want to mount the product.



3. Place the frame in the cabinet.



Attach the side bracket to the cabinet side using 6 screws.



2 Attach the side bracket to the frame using 3 screws. Use hole 1, 2 and 4. (Left side showed in the example).



4 Measure a minimum distance of 200mm from the cabinet bottom to the edge of the frame.



6. Insert bins, lid and divider.

