

# SELECT SIDE 600

## Assembly instruction

Mounted on cabinet side.



1. Turn the frame upside down and attach the side brackets to the frame.



2. Attach the side brackets to the frame using 3x2 screws. Use hole 1, 2 and 4.



3. Place the frame in the cabinet.



4. Measure a minimum distance of 200mm from the cabinet bottom to the edge of the frame.



5. Attach the side brackets to the cabinet sides using 6x2 screws.



6. Insert bins, lid and dividers.